


# Spare parts list

## CP 0122 S H22



No.	Description	Remark	Quantity	Part number
<b>1(2-9)</b>	<b>Handle, complete</b>		1	3303 0051 00
2	Handle		1	-
3	Pin - throttle lever		2	R133 757
4	Lever - throttle		1	F815 167
5	Bushing - throttle valve		1	P144 656
6	O-ring - throttle valve		1	P083 071
7	Valve - throttle		1	P144 202
8	Spring - throttle valve		1	C077 054
9	Nipple with gauze		1	F035 769
10	Upper valve case lid		1	F012 657
11	Valve case		1	F012 658
12	Valve		1	F012 659
13	Lower valve case lid		1	F012 656
14	Piston		1	F026 357
15	Dowel pin		2	F012 670
16	Handle lock pin		1	F001 919
17	Cylinder		1	-
18	Retainer locking ring		1	F035 269
19	Exhaust deflector		1	F012 747
20	Tool bushing	Hex 22 (7/8")	1	F814 164
21	Buffer	Hex 22 (7/8")	1	H230 4427
22	Retainer		1	C880 6427
<b>23(24-26)</b>	<b>Muffler, complete</b>		1	F814 201
24	Hose clamp		1	P052 726
25	Muffler		1	-
26	Screw		4	R140 630
27	Safety label		1	CA14 4007