


Y26 Rock Drill Parts Diagram



<i>Code</i>	<i>Description</i>
Y26-1	Water Pipe Swivel
Y26-2	Water Pipe Nut
Y26-2A	Air Plug Nut
Y26-3	Rubber Ring
Y26-4	Back Head
Y26-5	Water Tube Bush
Y26-6	Air / Water Tube
Y26-7	Ratchet
Y26-8	Plug
Y26-9	Valve Cover
Y26-10	Valve Chest
Y26-11	Valve
Y26-12	Valve Sleeve
Y26-13	Rifle Bar
Y26-14	On/Off Valve
Y26-15	Rifle Nut
Y26-16	Piston
Y26-17	Cylinder
Y26-18	Guiding Sleeve
Y26-19	Front Head
Y26-20	Chuck
Y26-21	Shank Bushing
Y26-22	Fastening Pin
Y26-23	Spring Pad
Y26-24	Hex Nut
Y26-25	Spring
Y26-26	Dowel Pin

<i>Code</i>	<i>Description</i>
Y26-27	Plug
Y26-28	Small Pad
Y26-29	Ratchet Pawl
Y26-30	Conical Spring
Y26-31	Drill Retainer Bolt
Y26-32	Drill Retainer
Y26-33	Drill Retainer Spring
Y26-34	Hex Nut
Y26-36	Hex Extra Heavy Nut
Y26-37	Side Bolt
Y26-38	Oil Plug
Y26-43	Spring
Y26-44	Operating Valve
Y26-45	Retaining Ring
Y26-46	Air Pipe Nut
Y26-47	Pad
Y26-48	Ring Seal
Y26-49	Air Pipe Swivel
Y26-50	Dowel Pin
Y26-51	Rubber Handle
Y26-52	Handle Bolt
Y26-53	Hex Nut
Y26-54	Operating Handle
Y26-55	On-Off Handle
Y26-61	Rubber Pad
Y26-64	Rubber Pad