

ITEM#	PART#	DESCRIPTION
NS	TX60041	Throt. Body Complete (<i>new style</i>)
1	TX60042	Throt. Body Bare (<i>new style</i>)
2	TX60043	Push Pin Bushing
3	TX60004	Throttle Lever
4	TX60005	Throttle Lever Fulcrum Pin
5	TX60044	Throttle Lever Lock Clip
6	TX60045	Throttle Ball (<i>new style</i>)
8	TX60046	Throttle Ball Spring (<i>new style</i>)
9	TX60047	Throttle Valve Plug (<i>new style</i>)
10	TX60011	Throttle Valve Plug O-Ring
11	TX60012	Oil Reservoir End Cap
12	TX60013	Connecting Pipe
13	TX60048	Push Pin
14	TX60014	Connecting Pipe Nut
15	TX60015	Oil Control Bushing
16	TX60016	Backhead
NS		Backhead Assbly. (# 11, 15-17)
17	TX60017	Oil Plug
18	TX60018	Lower Valve Block O-Ring
22	TX60019	Upper Valve Block
23	TX60020	Center Plate
24	TX60021	Valve Disc
25	TX60022	Lower Valve Block
26	TX60023	Valve Dowel Pin (2)
27	TX60024	Barrel
NS		Exhaust Deflector (Rubber)
28	TX60025	Exhaust Deflector (Steel)
30	TX60026	Plunger
31	TX60027	Upper Guide Bushing
32	TX60028	Guide Bushing O-Ring (2)
33	TX60029	Plunger Packing Set
35	TX60030	Lower Guide Bushing
36	TX60031	Packing Nut Lock Clip
37	TX60032	Packing Nut
38	TX00230BS	6" Malleable Iron Butt
40	TX60035	Clamp Screw

