

READ AND UNDERSTAND THE OPERATORS INSTRUCTION MANUAL THOROUGHLY BEFORE ATTEMPTING TO OPERATE THIS EQUIPMENT. Death or serious injury could occur if this machine is used improperly.

SAFETY MESSAGES



The safety instructions are proceeded by a graphic alert message of DANGER, WARNING, or CAUTION.



Indicates an imminent hazard which, if not avoided, will result in death or serious injury.



CAUTION

Indicates an imminent hazard which, if not avoided, can result in death or serious injury.

Indicates hazards which, if not avoided, could result in serious injury and or damage to the equipment.

GASOLINE Powered Equipment



 Do not operate gasoline powered equipment without adequate ventilation. Carbon monoxide is an invisible, odorless gas that can kill.

ELECTRICAL Powered Equipment



 ELECTRICAL HAZARD - Be sure equipment is properly grounded. Failure to comply could kill or result in serious injury.



WARNING

The engine exhaust from this product contains chemicals known to the State of California to cause cancer, birth defects or other reproductive harm.

GENERAL INSTRUCTIONS ·

- You must read and understand the operators instruction manual and all other manuals associated with this machine. For your safety and the safety of others around you, it is extremely important to fully understand how to operate this machine in the way it was intended. Different model machines or older/newer versions of the same model may have different parts and controls that you need to understand. If instructions are not readable or available DO NOT USE this machine and contact the factory for a replacement Manual.
- You must be able to physically handle the bulk weight and power of this machine. If not properly controlled this machine can cause death or serious injury.
- Do not operate this machine in an impaired mental state. You must be able to exercise good judgement and reactions to maintain a safe working environment.
- This is a "one person" machine which means only one operator can be operating the machine at any one time. For the safety of others, maintain a safe operating distance to other personnel. Your work area should be defined and appropriately marked so bystanders and coworkers do not stand or walk near this machine and end up seriously injured by flying debris or exposing them to harmful noise or dust.
- This equipment is for Commercial use. Although this is a "one person" machine your work team should understand how to shut this machine off and quickly get medical help if an accident strikes the operator.
- Keep all guards in place during operation. The guards are to provide protection from inadvertent contact with dangerous moving parts, pinch points, or hot surfaces.
- Wear appropriate Personal Protective Equipment (PPE) including safety glasses, safety boots, work gloves, respiratory protection,

hearing protection, and head protection. Do not wear loose clothing that can get tangled in moving parts. Failure to do so could result in dismemberment or death. Wear an approved respirator when removing hazardous materials or when grinding/cutting dry materials. Some dust particles such as concrete dust can contain silicate particles which can cause silicosis (a very serious lung disease). Contact NIOSH or OSHA for further details. When wet grinding/ cutting, avoid contact with the concrete/asphalt slurry which can

CAUTION

- cause serious skin irritations. You must maintain this machine per the maintenance schedule in the operator manual. Remember before adjusting, servicing, or fueling this machine, disconnect the source of power to the machine by disconnecting the spark plug (Gas models), or by unplugging the electrical power cord (electric models) or air hose (Pneumatic models) AT THE MACHINE so you can assure yourself it remains unplugged while you are working on it. Do not modify this machine. Use only genuine EDCO parts and accessories. Repairs and service should be performed by approved EDCO dealers or authorized technicians.
- You should look carefully around the area before you begin work so you can identify potential hazards such as deck inserts, pipes, columns, openings, electrical cords or outlets, or any other objects protruding from the slab surface.
- This machine has no brain so you must use your own. There is no substitute for safety. The safety decals on the machine are to serve as a reminder for information you must already know before you begin using this machine. Take a moment to reread the safety decals each time you use the machine. If your machine is missing any decals, contact the factory for a replacement (EDCO 1-800-638-3326).

	100 Thomas Johnson Drive, Frederick, MD 21702-4600 USA
Printed in USA	Phone (301) 663-1600 • 1-800-638-3326
©2005	Fax (301) 663-1607 • 1-800-447-3326
Page 2	Website: www.edcoinc.com · Email: sales@edcoinc.com



PARTS LIST MANUAL MODEL TLR-7

Section Page	Number
Safety Messages / General Instructions	2
How To Order Replacement Parts.	3
Illustration 1:Outer Frame Grouping	4,5
Illustration 2: Inner Frame Grouping	6,7
Illustration 3: Rotary Cutter Head Grouping	8,9
Illustration 4: Engine & Belt Drive Grouping	10,11
Limited Equipment Warranty	back cover

HOW TO ORDER REPLACEMENT PARTS

To insure product safety and reliability, always use genuine EDCO replacement parts when making repairs to the equipment.

□ When calling for parts, specify the MODEL and SERIAL NUMBER of the machine which can be found on the NAME PLATE. Keep that information in the space provided. In addition to this information, give part number, description and quantity as listed on the parts list to your parts representative.

□ Please note: Due to improvements and changes in the equipment, the illustrations shown may be different than the actual machine.

FILL IN INFORMATION BELOW

Date of Purchase _____

Name of Machine

Model # _____

Serial # _____


Belt Size(s)

Toll Free: 1-800-638-3326 FAX: 1-800-447-3326 email: sales@edcoinc.com

www.edcoinc.com



ILLUSTRATION 1 : OUTER FRAME GROUPING



Printed in USA ©2005 **Page 4**




		PARTS LISTING - ILLUSTR/	ATION	1 : OU	TER FRA	ME GROUPING	
ITEM#	PART#	DESCRIPTION	QTY.	ITEM#	PART#	DESCRIPTION	QTY.
1	68022	OUTER FRAME W/ HANDLE	1	27	68058	NUT, HEX NYLON JAM 3/4-10	2
2	68060	WEIGHT UNIT, 48 LB. (INCLUDES ITEMS 3-7)	2	28	10609	WASHER, LOCK, INT. TOOTH 3/4"	2
3	68037	WEIGHT, 41 LB.	2	29	10403	NUT, JAM 3/4-10	2
4	68038	WEIGHT BAR, 7 LB.	2	30	68020A	CASTER, SWIVEL, 5"WHEEL W/ 3/4-10 STEM	2
5	10312	WASHER, FLAT 1/2	4	31	68036	KICK STAND ASSY.	1
6	10045	WASHER, LOCK 1/2	4	32	68007	PAD, RUBBER, KICK STAND	1
7	68040	NUT, TAIL HANDLE 1/2-13	4	33	10053	SCREW, CAP 5/16-18 X 3/4	3
8	61108	GRIP, HAND 1" MODEL SX	2	34	10801	WASHER, LOCK 5/16	3
9	14023	KNOB, BALL 1-3/8 W/ 1/2-13THD, BLK.	1	35	10054	NUT 5/16-18	3
10	10953	FITTING, GREASE 1/8NPT STRAIGHT	1	36	68081	PLUNGER, SPRING 5/8-11 THD.	1
11	10359	SCREW, CAP 5/8-11 X 3-1/4	1	37	10046	NUT 5/8-11	1
12	10073	WASHER, FLAT 5/8	2	38	10318	SCREW, CAP 3/8-16 X 3-3/4	4
13	79035	BUSHING, RUBBER 1-1/16"OD X 5/8"ID	1	39	10811	WASHER, LOCK 3/8	4
14	68087	HANDWHEEL & LINKAGE SUBASSY.	1	40	10025	WASHER, FLAT 3/8	8
15	14023	KNOB, BALL 1-3/8 W/ 1/2-13THD, BLK.	1	41	68046	HOLDER, FRONTAXLE	2
16	65008	HANDWHEEL, SMALL W/ 5/8-8 X 18"ROD	1	42	10143	BOLT, TAP 1/2-13 X 1-1/2 (FULL THD)	4
17	50550	SLEEVE FOR 1/2" CAPSCREW, TAPERED	1	43	10045	WASHER, LOCK 1/2	4
18	10411	SCREW, SKT. HD.CAP 1/2-13 X 4 ZINC	1	44	10312	WASHER, FLAT 1/2	4
19	85005	BEARING, THRUST BALL 5/8	2	45	68045	AXLE SHAFT, FRONT 23"L	1
20	10073	WASHER, FLAT 5/8	3	46	10052	SCREW, SET 5/16-18 X 3/8	2
21	68086	LINKAGE SUPPORT, UPPER CONTROL	1	47	68047	SPACER, FRONTAXLE	2
22	10440	COLLAR, LOCKING 7/8"ID	1	48	50222	BEARING, BALL 1" TPB	2
23	10713	CLAMP, HOSE, SAE #24, ADJ. TO 2"	2	49	10006	FITTING, GREASE 1/8NPT X 45D	2
24	10930	BELLOWS 1-1/4ID X 2-3/8EL X 1-3/4RL	1	50	68008	WHEEL 8 X 1-5/8 X 3/4"BRG., POLY	2
25	10096	COLLAR, LOCKING 5/8"ID	1	51	10009	WASHER, FLAT 3/4	2
26	68043	LINKAGE, LOWER CONTROL 5/8-8 THD.	1	52	10306	PIN, COTTER 3/16 X 1-1/4	2
		(REFER TO ILLUS. 2, ITEM #13)					



Printed in USA

©2005

Page 6






DESCRIPTION FRAME, INNER TENSIONER, ENGINE (REFER TO ILLUS. 4-ITEM 10) BOLT, TAP 3/8-16 X 3-1/2(FULL THD.) SPACER, STEEL 5/80D X 3/8ID X 3/8THK BOLT, TAP 1/2-13 X 3 (FULL THREAD) NUT 1/2-13 COVER, BELT COVER, BELT COVER, BELT SCREW, CAP 1/4-20 X 3/4 WASHER, LOCK 1/4 WASHER, FLAT 1/4 THREAD-SERT 1/4-20, BLIND RIVET LINKAGE, LOWER CONTROL 5/8-8 THD. (REFER TO ILLUS. 1, ITEM #26)	QTY. 1 1 1 2 2 1 1 8 8 8 8 1
TENSIONER, ENGINE (REFER TO ILLUS. 4-ITEM 10) BOLT, TAP 3/8-16 X 3-1/2(FULL THD.) SPACER, STEEL 5/80D X 3/8ID X 3/8THK BOLT, TAP 1/2-13 X 3 (FULL THREAD) NUT 1/2-13 COVER, BELT COVER, BELT COVER REAR PANEL, BELT SCREW, CAP 1/4-20 X 3/4 WASHER, LOCK 1/4 WASHER, FLAT 1/4 THREAD-SERT 1/4-20, BLIND RIVET LINKAGE, LOWER CONTROL 5/8-8 THD.	1 1 2 2 1 1 8 8 8 8 8 8
BOLT, TAP 3/8-16 X 3-1/2(FULL THD.) SPACER, STEEL 5/8OD X 3/8ID X 3/8THK BOLT, TAP 1/2-13 X 3 (FULL THREAD) NUT 1/2-13 COVER, BELT COVER, BELT COVER REAR PANEL, BELT SCREW, CAP 1/4-20 X 3/4 WASHER, LOCK 1/4 WASHER, FLAT 1/4 THREAD-SERT 1/4-20, BLIND RIVET LINKAGE, LOWER CONTROL 5/8-8 THD.	1 1 2 2 1 1 8 8 8 8 8 8
SPACER, STEEL 5/80D X 3/8ID X 3/8THK BOLT, TAP 1/2-13 X 3 (FULL THREAD) NUT 1/2-13 COVER, BELT COVER REAR PANEL, BELT SCREW, CAP 1/4-20 X 3/4 WASHER, LOCK 1/4 WASHER, FLAT 1/4 THREAD-SERT 1/4-20, BLIND RIVET LINKAGE, LOWER CONTROL 5/8-8 THD.	1 2 1 1 8 8 8 8 8
BOLT, TAP 1/2-13 X 3 (FULL THREAD) NUT 1/2-13 COVER, BELT COVER, REAR PANEL, BELT SCREW, CAP 1/4-20 X 3/4 WASHER, LOCK 1/4 WASHER, FLAT 1/4 THREAD-SERT 1/4-20, BLIND RIVET LINKAGE, LOWER CONTROL 5/8-8 THD.	2 2 1 1 8 8 8 8 8
NUT 1/2-13 COVER, BELT COVER REAR PANEL, BELT SCREW, CAP 1/4-20 X 3/4 WASHER, LOCK 1/4 WASHER, FLAT 1/4 THREAD-SERT 1/4-20, BLIND RIVET LINKAGE, LOWER CONTROL 5/8-8 THD.	2 1 1 8 8 8 8 8
COVER, BELT COVER REAR PANEL, BELT SCREW, CAP 1/4-20 X 3/4 WASHER, LOCK 1/4 WASHER, FLAT 1/4 THREAD-SERT 1/4-20, BLIND RIVET LINKAGE, LOWER CONTROL 5/8-8 THD.	1 1 8 8 8 8 8
COVER REAR PANEL, BELT SCREW, CAP 1/4-20 X 3/4 WASHER, LOCK 1/4 WASHER, FLAT 1/4 THREAD-SERT 1/4-20, BLIND RIVET LINKAGE, LOWER CONTROL 5/8-8 THD.	1 8 8 8 8 8
SCREW, CAP 1/4-20 X 3/4 WASHER, LOCK 1/4 WASHER, FLAT 1/4 THREAD-SERT 1/4-20, BLIND RIVET LINKAGE, LOWER CONTROL 5/8-8 THD.	8 8 8 8
WASHER, LOCK 1/4 WASHER, FLAT 1/4 THREAD-SERT 1/4-20, BLIND RIVET LINKAGE, LOWER CONTROL 5/8-8 THD.	8 8 8
WASHER, FLAT 1/4 THREAD-SERT 1/4-20, BLIND RIVET LINKAGE, LOWER CONTROL 5/8-8 THD.	8 8
THREAD-SERT 1/4-20, BLIND RIVET LINKAGE, LOWER CONTROL 5/8-8 THD.	8
THREAD-SERT 1/4-20, BLIND RIVET LINKAGE, LOWER CONTROL 5/8-8 THD.	
LINKAGE, LOWER CONTROL 5/8-8 THD.	1
	1
PIN, DETENT RING 1/2 X 4 E.L.	1
	1
	1
	1
	1
	1
	1
	1
	1
	1
	1
	1
	1
	1
	1
	1
	1
,	1
	1
,	1
	2
	3
	18
	18
	18
· · · · · · · · · · · · · · · · · · ·	18
	4
	4
	2
	1
	4
	4
	1
	1
	PIN, DE TENT RING 1/2 X 4 E.L.HANDWHEEL, LARGE W/ 7/8-9 THD.SCREW, SKT. HD. CAP 1/2-13 X 4-1/2 ZINCSLEEVE FOR 1/2" CAPSCREW, TAPEREDKNOB, BALL 1-7/8 W/ 1/2-13THD., BLK.NUT, LOCK 5/8-11DECAL, PRESSURE CONTROL - MIN/MAX.THREAD INSERT 7/8-9 X 5/8-11BEARING, THRUST BALL 5/8WASHER, FLAT 5/8PLUG, CAP 3"LINKAGE, PRESSURE CONTROL 5/8-11COLLAR, LOCKING 5/8"IDNUT 1/4-28SCREW, CAP 1/4-28 X 1-3/4SPRING, EXT. 1.75"OD X 8"LGUARD & SKIRT SUBASSEMBLY(INCLUDES ITEMS 31-39)GUARD, CUTTER HEADSKIRT, RUBBERRETAINER, SKIRT 5-1/2"RETAINER, SKIRT 5-1/2"RETAINER, SKIRT 12"BOLT, CARRIAGE 1/4-20 X 1WASHER, FLAT 1/4WASHER, FLAT 1/4WASHER, FLAT 1/4WASHER, LOCK 1/4NUT 1/4-20SCREW, CAP 1/2-20 X 4-1/2WASHER, LOCK 1/4NUT, LOCK 1/2-20SPACER, ROTARY HEAD MAIN SHAFTSPIDER ASSY, ROTARY HEAD(REFER TO ILLUS. 3 FOR BREAKDOWN)



ILLUSTRATION 3 : ROTARY CUTTER HEAD GROUPING



Printed in USA ©2005 **Page 8**




PA	RTS LISTING -	ILLUSTRATION 3: ROTARY CUTTER HEAD GR	OUPING
ITEM#	PART#	DESCRIPTION	QTY.
1	68068	SPIDER ASSY., ROTARY HEAD	1
		(INCLUDES ITEMS 2-10)	
2	68011	SHAFT & FLANGE, ROTARY	1
3	10205	NUT, LOCK 1/2-20	3
4	68001	BUSHING, RUBBER 1-1/4 X 3/4 X 7/8	6
5	68065	HUB, ROTARY HEAD	1
6	68018	SLEEVE, RUBBER BUSHING	3
7	68013	FLANGE, ROTARY CUTTER HD BASE	1
8	10370	SCREW, CAP 1/2-20 X 3-1/4 (GRADE 8)	3
9	10126	PIN, ROLL 5/16 X 1-1/2	3
10	68066	SHAFT, ROTARY CUTTER	3
11	68067	FLANGE, ROTARY CUTTER INNER	3
12	68016	FLANGE, ROTARY CUTTER OUTER	3
13	10445	NUT, JAM 7/8-9 LEFT-HAND THREAD	6
14		TRI-CUT CARBIDE ASSEMBLY (SET OF 3)	1 SET
	26010	TR3-24 (24 CARBIDE PINS/CUTTER)	
	26020	TR3-48 (48 CARBIDE PINS/CUTTER)	
15		CUTTER, ROTARY	1 EA.
	68048	CUTTER ONLY, 24 CARBIDE PINS	
	68088	CUTTER ONLY, 48 CARBIDE PINS	
16	68017	SPACER 1-1/4"OD X 1"ID X 5/32"THK.	1 EA.
17	68004	BEARING, RADIAL BALL 25 X 62 X 17MM	2 EA.
18	68006	SEAL, FELT 2-1/2OD X 1-1/4ID X 3/16	2 EA.



E-TLR7-PL-0305

©2005

Page 10





ITEM# PART# DESCRIPTION 1 76004 ENGINE, HONDA 11 HP GXV340K2-DX3 2 10877 SCREW, CAP STSHW 10-24 X 1/2 3 40388 CABLE, THROTTLE, LEVER-TYPE 24" (TRIM TO 16")	QTY. 1 2 1 1 2
2 10877 SCREW, CAP STSHW 10-24 X 1/2	2 1 1
	1
	1
5 40500 CABLE, THIOTTEE, EEVENTHE 24 (TRIMITOTO)	
4 68033 MOUNT PLATE, ENGINE	2
5 10606 SCREW, CAP 5/16-18 X 1-1/4	-
6 10213 WASHER, FLAT 5/16	2
7 10801 WASHER, LOCK 5/16	2
8 10054 NUT 5/16-18	2
9 10056 BOLT, CARRIAGE 5/16-18 X 2	2
10 68035 TENSIONER, ENGINE	1
11 52015 BOLT, TAP 3/8-16 X 3-1/2(FULL THD.)	1
12 10011 SPACER, STEEL 5/8OD X 3/8ID X 3/8THK	1
13 68034 SPACER, ENGINE MOUNT	2
14 10225 BUSHING, RUBBER	4
15 10213 WASHER, FLAT 5/16	4
16 10801 WASHER, LOCK 5/16	4
17 10054 NUT 5/16-18	8
18 10048 SCREW, CAP 5/16-24 X 3/4	2
19 10801 WASHER, LOCK 5/16	2
20 76024 CLUTCH, CENTRIFUGAL 3.5 X 2GR X 1	1
21 KEY 1/4 SQ. (INCLUDED W/ ENGINE)	1
22 10251 BELT BP-34 (REFER TO SERIAL NO. PLATE)	2
23 75010 SHEAVE 6.9"OD X 2GR.B X SDS	1
24 10064 BUSHING, SHEAVE SDS X 1-1/4"BORE	1
25 10305 KEY 1/4SQ X 1-1/4	1
26 11543 BARB, PUSH-ON 3/8HOSEX20MMX1.50	1
27 56116 HOSE, PUSH-ON 3/8"ID X 3"L	1
28 11544 BARB, PUSH-ON 3/8HOSE X 1/4FPT	1
29 10776 PIPE PLUG 1/4 NPT (BRASS)	1



LIMITED EQUIPMENT WARRANTY

Equipment Development Company, Inc. herein referred to as EDCO warrants that each new unit manufactured by EDCO to be free from defects in material and workmanship in normal use and service for a period of (1) one year (except in the case of the cutter drum assembly on all model concrete asphalt planes, in which case the warranty period shall be 90 days) from date of shipment to the original buyer or equipment rental center owner.

EDCO will, at its option, repair or replace, at the EDCO factory or at a point designated by EDCO any part, which shall appear to the satisfaction of EDCO inspection to have been defective in material or workmanship.

This warranty, does not apply to failure occurring as a result of abuse, misuse, negligent repairs, corrosion, erosion, normal wear and tear, alterations or modifications made to the product without express written consent of EDCO: or failure to follow the recommended operating practices and maintenance procedures as provided in the products operating and maintenance manuals.

This warranty does not obligate EDCO to bear any transportation charges in connection with the replacement or repair of defective parts. This warranty does not obligate EDCO to bear any expense for travel time or of personnel in connection with any service calls.

Accessories or equipment furnished and installed on the product by EDCO but manufactured by others, including but not limited to engines, motors, electrical equipment, transmissions, etc., shall carry the accessory manufacturers' own warranty.

THIS WARRANTY IS IN LIEU OF ALL OTHER WAR-RANTIES, EXPRESSED OR IMPLIED, OR STATU-TORY, INCLUDING ANY WARRANTIES OF MER-CHANTABILITY OR OF FITNESS FOR A PARTICU-LAR PURPOSE.

LIABILITY LIMITATIONS

The remedies of the user set forth under provisions of warranty outlined above are the exclusive and total liability of EDCO with the respect to their sale or the equipment and service furnished hereunder, in connection with the performance or breach thereof, or from the sale, delivery, installation, repair or technical direction covered by or furnished under the sale, whether based on contract, warranty, negligence, indemnity, strict liability, or otherwise shall not exceed the purchase price of the unit of equipment upon which such liability is based.

EDCO will not in any event be liable to the user, any successors in interest or any beneficiary or assignee relating to this sale for any consequential, incidental, indirect, special or punitive damages arising out of this sale or any breach thereof, or any defects on, or failure of, or malfunction of the equipment under this sale based upon loss of use, lost profits or revenue, interest, lost goodwill, work stoppage, impairment of other goods, loss by reason of shutdown or non-operation, increased expenses of operation of the equipment, cost of purchase or replacement power of claims of users or customers of the user for service interruption whether or not such loss or damage is based on contract, warranty, negligence, indemnity, strict liability, or otherwise.

EDCO reserves the right to modify, alter and improve any part or parts without incurring any obligation to replace any part or parts previously sold without such modified, altered or improved part or parts.

No person is authorized to give any other warranty or to assume any additional obligation on EDCO's behalf unless made in writing and signed by an officer of EDCO.


Equipment Development Company, Inc.

USE ONLY GENUINE EDCO PARTS AND ACCESSORIES For your own safety, the safety of others and the life of your machine

	100 Thomas Johnson Drive, Frederick, MD 21702-4600 USA
Printed in USA	Phone (301) 663-1600 • 1-800-638-3326
©2005	Fax (301) 663-1607 • 1-800-447-3326
Page 12	Website: www.edcoinc.com · Email: sales@edcoinc.com



E-MCK11H-PL-0605





100 Thomas Johnson Drive, Frederick, MD 21702-4600 USA Phone (301) 663-1600 • 1-800-638-3326 Fax (301) 663-1607 • 1-800-447-3326 Website: www.edcoinc.com • Email: sales@edcoinc.com

Printed in USA ©2005